

- Category B crown
- Category C crown
- Tree to be removed shown as dotted outline (colour according to category)
- Root Protection Area
- Protective Barrier
- ▨ Ground Protection Area
- ▨ No Dig Area

Special measures in the form of Cellweb as a No Dig solution to be used within the RPA of T9 to protect the tree roots.

RPA's of T1 and T4 offset by 20% to field (concrete drive between tree and site has been in place since the 1960s, so likely that the majority of the tree roots have grown into the field, rather than struggle to grow through the compacted ground beneath the drive area)

Special measures in the form of Ground Protection to facilitate working space to be used within the RPA of T1 and T4 to protect the tree roots.

Special measures in the form of Cellweb as a No Dig solution to be used within the RPA of T1 to protect the tree roots.

