

Simple crevice bat "box"

for use internally in attics etc.

The battens go between the two planks, with the one long side left open. Mounted inside the attic as high as possible, horizontally, with the open edge facing downwards. Best site is strapped under the apex beam. Mount 2 or 3 at least in the attic to provide varying temperature conditions, with 1 at least of those under a southerly pitched section.

